

# Snowboard bracket kit Mounting Instructions

## Step #1

Remove contents.



16" strap with ratchet and strap saver

Rear snowboard bracket with 8" strap and 220mm ladder. Front snowboard bracket



## Step #2 Tools required

7/16" open end wrench, 3" socket ext, socket ratchet, 7/16" socket 5/8", 17/64" and 1/8" drill bits--Drill--Tapping tool with 1/4" Tap (optional) and thread lock.

## Step #3



Take the DD rack and secure on a work bench. Drill using 1/8" bit in DD rack into pre punched hole marks. 4 holes total. Two verticle and two horizontal. Finish drilling with 17/64" bit in all four holes. The front horizontal hole needs to be drilled out using the 5/8" drill bit.

## Step #4

Take all hardware off of pieces.



## Step #5

Mount the front snowboard bracket on the DD rack like shown. Put a washer on 2 3/4" bolt. Use the 7/16ths ratchet and ratchet bolt through piece until the bolt threads are showing on the bottom. Place a washer and nut on the bottom threads and hand tighten. If holes drilled do not line up with holes in bracket. Remove piece and drill out holes next size bigger until all holes line up.



## Step #6

Grab the 1 3/4" bolt and 1/4" washer. Put bolt into longest setting of 16" strap and spacer block. Put a dab of threadlock on the end of the threads sticking out.

