

Step#10

Drill 1/8" hole first and finish off with the 3/16" drill bit in two marked spots.

Step#11

Pull out the rivet gun and the 68 rivets and washers. Put rivet through hole in bracket and into snowmobile. Place washer on the back of rivet inside the tunnel if possible.(If you cant get to it skip) Rivet and repeat on other hole



Step #12

Adjust strap size.Tighten bolt holding strap with ratchet,7/16" socket and open end wrench.

Step #13

Leave the ski in the rack. Go were the ski hits the running boards. Grab the U channel and place it under ski. Remove the ski and grab your marker pen. Mark a hole in the bolt hole of U channel on running board. Remove the u channel. Look under neath running board where hole is marked. Is there anything underneath that i will damage by drilling a hole here? If no then proceed to use your hole punch and hammer and mark spot. Go and grab your drill and Drill two holes with 1/8" drill bit first and finish with 3/16" .

Step #15

Repeat on other side and go sled skiing A.S.A.P

Any question or problems contact

1-877-894-1880 Cheetahfactoryracing.com

